


Written By: Noor Assaf



INTRODUCTION

Bad connections between the phone itself and the handset could be an issue. Replacing the defective internal phone jack will solve this problem.



TOOLS:

- [Precision Tweezers Set](#) (1)
 - [Metal Spudger Set](#) (1)
-

Step 1 — Back Panel



- Remove five 9.5 mm Phillips #1 screws from the back panel of the phone.


Step 2




- Slide metal spudger into the crack around the Front Panel of the phone



⚠ Be careful not to break the clips holding the Back Panel to the Front Panel


Step 3




 When setting the back panel down, be careful to not rip any of the wires off of the internal components

Step 4 — Phone Jack



- Using the precision tweezers, bend the golden tips of the green and red wires upward.
-  The wires are pulled out from two wholes out of six whole. Make sure you remember which whole you pulled the wire out from.
- Bend the wires slowly and gently to avoid breaking them.

Step 5



- After bending the golden wire tips, pull the wires out from the back side of the phone jack.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 09:41:30 PM.